




# TOP AND CABINET PARTS

For Model: LSR5232LQ0  
(Designer White)

AUTOMATIC  
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CABINET PARTS

For Model: LSR5232LQ0  
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Installation Instructions
	LIT3952817	English
	LIT3951578	French
		Use & Care Guide
	LIT3955156	English
	LIT3954821	French
	LIT3954565	Wiring Diagram
	LIT3954871	Energy Guide

## Following May Be Purchased


### DO-IT-YOURSELF REPAIR MANUALS

	LIT4313896	Manual, Do-It Yourself (Washer)
2	8274315	Top
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push-In (2)
5	63424	Cabinet
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3357011	Screw, 10-16 x 1/2
8	3356311	Screw & Washer, Lid Switch (2)
11	3949237	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	91770	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19	3361411	Lid
20	358684	Strike, Lid Switch
22	9724509	Bumper, Lid (2)
28	3390631	Screw, 10-16 x 3/8 (5)
31	90016	Clip, Harness

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROLS AND REAR PANEL PARTS

For Model: LSR5232LQ0  
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROLS AND REAR PANEL PARTS


For Model: LSR5232LQ0  
(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)	10	3351614	Screw, Ground	32	3951449	Hose, Pump To Tub
2	9740848	Screw, 8-18 x 1/2	11	90767	Screw, 8-18 x 3/8	33	8055003	Clip, Harness & Pressure Hose
3		Hose, Water Inlet (2)	12	3366849	Switch, Water Level	35	3400073	Screw, 10-24 x 5/16
	3949374	Blue Coupler	13	3948608	Bracket, Control	36	3400818	Screw, Timer Mounting
	3949375	Red Coupler	14	3948063	Cord, Power	39	3955390	Panel, Console
5	8318255	Strap, Console (2)	15	3952821	Strain Relief, Power Cord	44	8271345	Knob, Timer
6	3357978	Panel, Rear	16	8271365	Cap, End (L.H.)	45	8271351	Dial, Timer
7	62747	Pad, Rear Panel	17	661606	Capacitor	47	8271339	Knob, Control
8	3951609	Hose, Drain (4 ft.)	18	3952164	Valve, Water Mixing	49	388326	Screw, 8-18 x 1.25 (Panel to Top)
	661577	Hose, Drain (9 ft.) (Not Included)	19	3976395	Clamp, Hose	50	62863	Screw, 10-16 x 3/8
	3357090	Extension Drain-Hose (21 Inches) (Not Included)	20	8318201	Clip, Capacitor	51	8271359	Cap, End (R.H.)
9	3954563	Timer, Control (60 Hz.) (Motor Not A Service Part)	21	370451	Clamp, Hose	55	3976286	Shield, Capacitor
			22	3357328	Hose, Vacuum Break	58	3366913	Clamp, Drain Hose
			23	371503	Clamp, Hose	59	3348424	Shield, Suds
			24	387606	Break, Vacuum	60	3357027	Nozzle-Drain Hose
			25	8519200	Support, Rear Panel	61	3955029	Wiring Harness (For Detail See Page 9 & 10)
			26	8317940	Drain Hose Assembly			
			27	3366912	Clamp, Hose			
			30	3363366	Clamp, Hose			
			31	8317496	Clamp, Hose			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AGITATOR, BASKET AND TUB PARTS

For Model: LSR5232LQ0  
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# AGITATOR, BASKET AND TUB PARTS

For Model: LSR5232LQ0

(Designer White)


Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer (5/16-24 x 1)
4	63235	Agitator
5	63851	Tub Ring & Gasket
6	3359585	Gasket, Tub Ring
12	21366	Nut, Spanner
13	3951989	Basket & Balance Ring (Also Order #14)
14	8522271	Filter Plug
16	63849	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
24	3949550	Washer

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: LSR5232LQ0


(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MACHINE BASE PARTS

For Model: LSR5232LQ0  
(Designer White)




Illus. No.	Part No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting (3) (10-32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus. 6, 7, 8, 9, 16, 17 18 & 26)
21	3359452	Nut, Lock (3/8-16) (2)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST



# WIRING HARNESS PARTS

For Model: LSR5232LQ0  
(Designer White)



WH2G

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WIRING HARNESS PARTS

For Model: LSR5232LQ0

(Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	23	3349494	Connector, Etc
2	388498	Clip, Harness				24	60687	Connector, Relay (Use Term.308569)
3	3347812	Clip, Harness				25	3407125	E.T.C. Control
4	3352501	Clip, Harness	14	3347243	Block, Disconnect (Use Term. 352088)	26	3948617	Connector (T.P.A.) (3-Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.)
5	90016	Clip, Harness	15	63523	Protector			
6	3390496	Clip, Harness	16	717252	Connector (2-Way) (Use Term.94614)	27	3360056	Connector (T.P.A.) (3-Circuit) (Pressure Switch) (Use Term.3948619 OR 3948620.)
7	389379	Retainer, (Suds Models)	17	387566	Plug, Terminal (4-Way) (Power Cord) (Use M3 Screws)	28	3354925	Block, Connector (Cold Valve) (Use Term.693217)
8	352090	Timer, Block Disconnect (White)	18	3352944	Clip, Harness	29	3354926	Block, Connector (Hot Valve) (Use Term.693217)
9	352089	Timer, Block Disconnect (Black)	19	3390423	Block, Disconnect (12-Way) (Timer) (Use Term. 94613)	30	3948615	Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3-Way) (Lid Switch) (Use Term.94613) Or 94614.)	20	3347730	Receptacle (6-Way) (Use Term. 94613)			
11	353424	Plug, Terminal (3-Way) (Power Cord) (Use Term.94613)	21	388818	Plug, Terminal (12-Way) (Use Term. 94613 Or 94614.)			
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)			


**FOR COMPLETE WIRING HARNESS REFER TO  
CONTROL AND REAR PANEL PARTS PAGE**

WH2G

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BRAKE AND DRIVE TUBE PARTS

For Model: LSR5232LQ0  
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining


## FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant  
(Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# GEARCASE PARTS

For Model: LSR5232LQ0  
(Designer White)




Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10-24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# WATER SYSTEM PARTS

For Model: LSR5232LQ0  
(Designer White)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# MISCELLANEOUS PARTS

For Model: LSR5232LQ0  
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	Washer, Inlet Hose (4) (1-1/16 x 5/8)
4	3359452	Nut, Lock (3/8-16)
5	389102	Foot, Front (2)
6	3366913	Clamp, Hose
7	3366912	Clamp, Hose

## OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
<b><u>PAINT, TOUCH-UP (1/2oz.)</u></b>		
	72017	White
<b><u>PAINT, PRESSURIZED SPRAY (12 oz.)</u></b>		
	350938	Primer, Gray
	350930	White
<b><u>PAINT, BULK (1 qt.)</u></b>		
	799344	White (Uncut)

Illus. No.	Part No.	DESCRIPTION
<b><u>OIL</u></b>		
	350572	Oil, Gearcase (16 Oz.)
<b><u>LUBRICANT</u></b>		
	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

Illus. No.	Part No.	DESCRIPTION
<b><u>SEALER</u></b>		
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
<b><u>SHIPPING KIT</u></b>		
	3348675	Shipping Kit
<b><u>ACCESSORY PARTS</u></b>		
	63580	Fabric Dispenser
	367031	Drain Protector
	285320	Siphon Break Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST